

# Retention Kit Installation Instructions

## AMD AM4

### Step 1

Remove stock AM4 mounting hardware by loosening the four screws, and removing the two plastic pieces. Keep the backplate in place.

### Step 2

Screw standoffs onto the backplate while holding it in place. Tighten firmly.

### Step 3

Secure retention ring to the pump / block combo. Attach from the side that will contact the CPU. Swivel and click into place. NOTE: For Asetek Gen4 pumps, use the plastic retention clip to secure the pump to the retention ring after it is placed in the desired orientation.

### Step 4

Install fans to radiator and install radiator in case. Orient the fans as intake if you want the best performance.

### Step 5

Align the holes of the retention ring with the stand-offs on the motherboard. Place the pump/block onto the CPU.

### Step 6

While holding the pump/block combo on your CPU, tighten down the four (4) thumbnuts with your fingers and then tighten them down with a screwdriver.

### Step 7

Connect the fans to appropriate headers on the motherboard. Connect the pump to CPU\_FAN header on your motherboard.

## Community and Support



Join our community  
on Discord.