## Input Guide - Assetto Corsa EVO



Go to the settings menu and select the controls menu.

When you enter this menu, select your wheelbase (in this case Invicta wheelbase is displayed).

к	eyboard	l & Mouse Fo	rte Steering Wheel	Button Box Invicto	I Pedals Invicta Who	eelbase Invicta Pedals
Ľ	Car	UI	Camera	Showroom	Modifiers	
I	AXIS	Steering				
I	AXIS	Throttle				
	AXIS	Brakes				

Click on steering and map your axis.

When assigning your pedals, choose your pedals on the top bar (in this case, Invicta

## pedals) click on the throttle, brake and clutch (if any) to calibrate.

Ke	eyboard	d & Mouse	Forte S	teering Wh	eel Button Bo	k Invicta Pe	dals Invicta	Wheelbase	Invicta Pedals	T500 RS G	ear Shift 🛛	XInp
	Car	UI	34	Camera	Show	room	Modifiers					
	AXIS	Steering										
	AXIS	Throttle									O	
	AXIS	Brakes									1	
	AXIS	Clutch									2	
	AXIS	Handbrak	œ									
	Steer	Left										

After you have mapped your the pedals, you need to invert the pedals. Start by clicking on the throttle pedal and click properties on the right side.

Properties	Settings	TrackIR	I man	/	<u>í – í –</u>	a de la composición de la comp
		Invert Axis	ls Slider	1		
Deadzone				T		0%
Saturation X	//		1	-	1	100%
Saturation Y	//		=/	7		100%
Curvature						0%
		REBIND	CLEAR BINDING			

Click invert axis. Repeat this process with all your pedals.

## Set up your steering wheel by choosing your steering wheel on the top bar (in this case Forte Steering wheel).

Keyboard & Mouse Fo	orte Steering Wheel But	ton Box Invicta Pedals	Invicta Wheelbase	Invicta Pedals	T500 RS Gear Shift	XInput
Car UI	Camera	Showroom Mo	difiers			
Hanadrake						
Clutch						
Paddle Gear Up					31	
Paddle Gear Down					29	
Shifter Gear 1						
Shifter Gear 2						

Map the buttons you want to use.

If you are using the clutch pedals, go to top with the axis bindings, and map the axis.

Ke	yboard	d & Mouse	Xinput	Controller	T500 RS	Gear Shift	Invicto	a Pedals	Invicta W	heelbase	Forte Ste	ering Whe	el Button Box
	Car	UI	23	Camera	Sh	iowroom		Modifier	S				
	AXIS	Steering											
	AXIS	Throttle											
	AXIS	Brakes											
	AXIS	Clutch											٥
		11 an dhual											

Ensure to invert the clutch paddle axis, by clicking op properties, and clicking invert axis.

Properties	Settings	TrackIR			
		Invert Axis	Is Slider	1 ==	
Deadzone		and the second second		7	0%
Saturation X	1/			- 1	100%
Saturation Y	/		$1 \leq \epsilon$		100%
Curvature	and the second s				0%
	-7	REBIND	CLEAR BINDING		

Your equipment are now assigned!